

Connect the analog camera to the computer

important By default Windows 10 computers have the option Fast startup enabled. This means that the computer goes into standby instead of shutting down when you switch off the computer. This can sometimes cause MediaRecorder to stop responding when selecting an input of the H.264 video capture card. Therefore, for analog cameras it is especially important to select the correct power options. See [Select correct power options](#) in [The steps to install MediaRecorder](#).

The connectors on the Picolo Alert PCIe video capture card

The Picolo Alert PCIe card has 4 BNC connectors. This card has an effective delivery bandwidth of 180MB/s.

[image.png](#) and or type unknown

To connect the camera

If your camera has a BNC output connector, connect a coaxial cable, with BNC connectors on both sides, between Video Out of the camera and one of the BNC inputs of the breakout cable.

[image.png](#) and or type unknown

If your camera does not have a BNC connection, use a converter.

Revision #7

Created 29 November 2023 22:51:49

Updated 2 January 2024 16:48:50