


# Connect the USB 3 cameras to the PC


Connect the cameras to the USB 3 interface card of the MediaRecorder computer.

Image not found or type unknown

**TIP** USB 3 connectors and ports can be recognized by their blue color coding.

Image not found or type unknown

Or by a double-S in front of the USB icon.

Image not found or type unknown

## Important note

- Using multiple Basler USB 3 cameras with a laptop is not supported.

---

Revision #3

Created 1 December 2023 11:20:49

Updated 2 January 2024 21:44:46